

Basic Specifications	
Color Range	RGB/RGBW/W
Working Voltage	DC 24V
Max. Power Consumption	9W/12W/15W/18W
Light Source	36/48/60 pcs LEDs
LED chip Brand	Optional(Cree, OSRAM, Lumileds, Epistar, etc)
CRI	80
Control	DMX512, ON/OFF
Segment	1/4/5/6/8/10
Source Life	50,000 h
Housing	High strength aluminum alloy
Cover	PC(Transparent, Opal)


## 深圳爱克莱特科技股份有限公司


Shenzhen EXC-LED Technology Co., Ltd



Weight	0.43Kg
Working Temperature	-40°C to 60°C
Storage Temperature	-40°C to 70°C
Protection Rating	IP66
Efficiency flux	40LM/W(White), 20LM/W(RGB), 30LM/W(RGBW)milky diffuser(decrease 30%-50%)
Beam Angle	≥95°
Host Controller	EXC-5200
Slave Controller	EXC-2905T1
Signal Cable	EXC-LED outdoor special cable

## **Light Intensity Distribution**









## Installation Diagram


### 1. Facade installation

1. Fix the elastic buckle on the mounting carrier with screws.




2. Install the lamp onto the elastic bracket, and fix the lamp with the elastic buckle.





Schematic diagram of section

3. Complete the effect diagram of installation.





Schematic diagram of section



Remove one end cap Schematic Diagram of Section

# 深圳爱克莱特科技股份有限公司

Shenzhen EXC-LED Technology Co.,Ltd

#### 深圳市光明区凤凰街道塘家社区科农路589号爱克股份产业园1栋101 101, Building 1, EXC Stock Industrial Park, No. 589, Kenong Road, Tanglia Community, Fenghuang Street, Guangming District, Shenzhen


Http://www.exc-led.com

E-mail: exc@exc-led.com


Tel: 4008-777-189




 Use ST4 self-tapping screws to fix the mounting seat to the position of the mounting carrier as shown in the figure, with the specific spacing to be required by the lamp length.



2. Clamp the lamp on the mounting seat, and then use M4 screws to lock the lamp through the mounting seat. Secure the installation.



3. Finally, connect the male and female connectors of the waterproof joint line through threads as shown in the figure, and secure the installation.



# 深圳爱克莱特科技股份有限公司


Shenzhen EXC-LED Technology Co.,Ltd



### System connection diagram:

- 1. Host controller should connect with slave controller. Working voltage for controllers are AC220V.
- 2. On-line main controller should connect with slave controller, on-line main controller and sub controller working voltage are AC220V.
- 3、each sub-controller with 8 ports, with each port 512 pixels, supporting data converter, supports 100 meters ultra-long haul transmission.
- 4. The CAT-5 e. cable distance should be within 100 meters between host controller and slave controller, between slave controllers and switch, etc.

## Offline Controlling System Diagram



## 深圳爱克莱特科技股份有限公司

Shenzhen EXC-LED Technology Co.,Ltd



